

ITEM #0041389




Holiday Living & Design® is a registered trademark of LF, LLC. All Rights Reserved.

BATTERY-OPERATED CANDLE

MODEL #W13B0005

Español p. 3



Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-800-643-0067, 8 a.m. - 6 p.m., EST, Monday - Thursday, 8 a.m. - 5 p.m., EST, Friday.

AB13330

SAFETY INFORMATION

WARNING: This is not a toy and not intended for children.

- Do not dispose of batteries in a fire as they may explode or leak.
- Do not mix old and new batteries and do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Use type "AA" batteries.

Safe for indoor use.

PROPOSITION 65 WARNING: This light bulb/lighting product has one or more soldered electrical connection points on its base that contain LEAD (or lead compounds). LEAD is a chemical known to the State of California to cause cancer and birth defects (or other reproductive harm). Please take steps to minimize handling of the base of this product. Please do not place the base of the bulb in mouth.

HOW TO REPLACE THE BULB:

- Unscrew the lamp from the base counterclockwise (Fig. 1).
- Replace with a 3 volt bulb.
- Tightly screw the bulb to the base clockwise (Fig. 2).




Fig. 1 Fig. 2

HOW TO INSTALL/REPLACE THE BATTERY:

- Unscrew the bulb with ring from the base counterclockwise (Fig. 3).
- Place two new AA batteries (not included) according to "+" and "-" direction in the base (Fig. 4).
- Tightly screw the bulb to the base clockwise (Fig. 5).




Fig. 3 Fig. 4 Fig. 5

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
The product does not light.	1. The bulb is loose or out of the base.	1. Gently screw the bulb firmly into the base.
The bulb is broken.	1. The bulb was impacted or shifted during transport.	1. Replace the broken bulb with a new bulb.
A bulb has burned out.	1. Incorrect bulb or voltage is too high.	1. Replace any burned-out bulbs as soon as discovered.

Printed in China




ARTÍCULO #0041389

VELA A BATERÍAS

MODELO #W13B0005

Holiday Living & Design ® es una marca registrada de LF, LLC. Todos los derechos reservados.



¿Preguntas, problemas, piezas faltantes? Antes de volver a la tienda, llame a nuestro Departamento de Servicio al Cliente al 1-800-643-0067, de lunes a jueves de 8 a.m. a 6 p.m., y de 8 a.m. a 5 p.m. los viernes, hora estándar del Este.

INFORMACIÓN DE SEGURIDAD

ADVERTENCIA: este producto no es un juguete y no está destinado para los niños.

- No incinere las baterías ya que podrían explotar o filtrarse.
- No mezcle baterías viejas y nuevas. No mezcle baterías alcalinas, estándar (carbono-zinc) o recargables (níquel-cadmio).
- Use baterías tipo "AA".

Seguro para uso en interiores.

ADVERTENCIA DE LA PROPUESTA 65: Esta bombilla/producto de iluminación contiene uno o más puntos de conexión eléctrica soldados en su base que contienen PLOMO (o compuestos de plomo). El PLOMO es un elemento químico reconocido por el estado de California como causante de cáncer y defectos congénitos u otros daños en el aparato reproductivo. Tome las medidas necesarias para minimizar la manipulación de la base de este producto. No se ponga la base de esta bombilla en la boca.

CÓMO REEMPLAZAR LA BOMBILLA:

- Destornille la lámpara de la base en dirección contraria a las manecillas del reloj (Fig. 1).
- Remplace por una bombilla de 3 voltios.
- Atornille firmemente la bombilla a la base en dirección de las manecillas del reloj (Fig. 2).




Fig. 1 Fig. 2

CÓMO INSTALAR O REEMPLAZAR LA BATERÍA:

- Destornille la bombilla con anillo de la base en dirección contraria a las manecillas del reloj (Fig. 3).
- Coloque dos baterías AA nuevas (no incluidas) según las direcciones "+" y "-" en la base (Fig. 4).
- Atomille firmemente la bombilla a la base en dirección de las manecillas del reloj (Fig. 5).




Fig. 3 Fig. 4 Fig. 5

SOLUCIÓN DE PROBLEMAS

PROBLEMA	CAUSA POSIBLE	ACCIÓN CORRECTIVA
El producto no enciende.	1. La bombilla está suelta o fuera de la base	1. Asegure la bombilla firmemente pero sin forzarla dentro la base.
La bombilla está rota.	1. La bombilla chocó o se sacudió durante el transporte	1. Reemplace bombilla rota por una nueva.
Una bombilla está quemada.	1. Bombilla incorrecta o el voltaje es muy alto	1. Reemplace las bombillas apenas se quemén.

Impreso en China