

7' KENDALL UNLIT

MODEL NO: U09G432M-029-01

ASSEMBLY INSTRUCTIONS

**PRODUCT CODE:
M29392**

**CAUTION:
Carefully Read
Instructions and
Procedures for
Safe Operation**



Receipt of Purchase:


Questions, problems, or missing parts?
Before returning to place of purchase,
please contact us at 866-210-5958.
7 am - 9 pm, CST, Monday-Friday.
Willis Electric customer service
representatives will be glad to assist
you.

**UPC CODE:
0 30539 056384**


Attach Here

ASSEMBLY INSTRUCTIONS





1. Before you start to assemble your tree, place the tree stand on a level surface.
2. Assemble tree stand according to the assembly instruction for the tree stand.
3. Insert the bottom section (C) of the trunk into the assembled stand (D). (See Fig.1)
4. Insert the middle section (B) into the bottom section (C), the upper section (A) into middle section (B). (See Fig.2,3)
5. Open all the branches. (See Fig.4)



6. Allow the branches to fall into place or gently pull branches up and out. When adjusting branches be sure that all wires are free of branch hinges. (See Fig.5)
7. Shape the branches. Starting with tips closest to the pole, shape one tip to the right, one to the left and one at the center of the main stem. Repeat pattern for each branch.



ASSEMBLY INSTRUCTIONS FOR TREE STAND

1. Tree stand consists of a metal stand and a single eye bolt. (See Fig.1)
 
2. Open the stand to a 90 degree angle until the hole lines up with the hole on the tube. (See Fig.2)
 
3. Insert an eye bolt and screw into the hole. (See Fig.3)
 
4. Insert the tree into the stand and adjust accordingly. The tree should be straight and balanced correctly. (See Fig.4)
 

STORAGE: Disassembled tree can be stored in its original box. Store tree in a cool dry place where the temperature does not exceed 100 degrees Fahrenheit.